



1. Pull the playfield forward a bit to get clearance between the field backboard and the metal frame wall that's part of the cabinet.
2. After mounting the mod to that back corner, drop the cable behind the backboard so the wire rests on the side (see 1st photo).
3. Pull up the playfield to run the wire down the cabinet. The cable management that is already there can be used to tuck the cable out of the way (see 2nd photo). Make sure all the extra slack rests on the back part of the cabinet underneath the head (where the mod is).
4. We will be using the CN2 connector at the node at the front of the cabinet. Connector only goes in one way in relation to the top or bottom side, but needs to be aligned to the farthest right (or towards the back). It hugs next to the existing connector (see photo below).
5. When putting the playfield back in place, help hold the cable in place between the backboard and the cabinet metal guard so it does not pinch or get stuck.

